



EN ISO 20345:2011



CRYSTAL
VENEZIA

86203-00

S2 SRC

Size: 35-39 40-48

Weight: 460 gr.

Working Environment:

Food and Chemical industry

FEATURES

UPPER

MicroFiber Xtop

LINING

Bacteriostatic Teklife 2D

ANTISLIP LINING

DUALMICRO

INSOLE

Flyfit

TOE CAP

CTC- Composite Toe Cap

TYPE

Low Shoe

SOLE

PU DUAL-DENSITY SRC

Double density PU outsole with tread designed mainly for indoor use. Self-cleaning design and highly non-slip grip. SRC Antislip standard.

TECHNOLOGIES

Removable Insole



The upper layer in contact with the foot is made of a highly resistant netting to ensure exceptional absorption of dampness. A self-forming antibacterial foam layer ensures comfort and correct support of the foot.



Protection elements



Composite Toe Cap

Toecap made of plastic, incredibly light and resistant to impact of over 200J, very high elastic coefficient, immediately regaining the original shape without entrapping the toes. Perfect thermal isolation. Not detected by metal detector.



SRC (SRA+SRB)



SOLE 86
PU - PU

SRA CERAMIC + DETERGENT SOLUTION	FLAT ≥0.32	0.40
	HEEL (CONTACT ANGLE °) ≥0.28	
SRB STEEL + GLYCEROL	FLAT ≥0.18	0.19
	HEEL (CONTACT ANGLE °) ≥0.13	

EN ISO 20344:2011

Lateral stability

dynamic **HC** control
technology

Ergonomic rigid internal structure. It houses the heel into the right seat, adjusting the foot support and control of the ankle sideways movements. It keeps the foot tight to the shoe, allowing the perfect fit.



Torsional stability

STABIL•ACTIVE

Support made of rigid plastic material. It stabilizes the heel bone, the instep and tarsal joints, without altering energy absorption. A support for the natural movement of the foot; it provides comfort and greater stability.



Electrical features



Wire Electricity Discharge

Strip with 4 filaments of carbon fiber, ensuring proven anti-static properties of the footwear over time.



Other

DUALMICRO
DUALMICRO

Double non-slip layer of microfibre, resistant up to 200,000 cycles. Makes the footwear more comfortable, blocking the foot during use.